

# Cerberus PRO

## 252-Point and 504-Point Addressable (FIRE-Only) Control Panel Models FC922 and FC924

### ARCHITECT AND ENGINEER SPECIFICATIONS

- Addressable fire alarm control panel (FACP) intended for mid-size building applications
- Comprised of the following system components:
  - Operating units
  - Periphery boards
  - Power supplies
  - System enclosures
- System features:
  - Supports 252-to-504 addressable devices:
    - One (1) to four (4) 'Class B'; one (1) to two (2) 'Class A' for Model FC922
    - One (1) to eight (8) 'Class B'; one (1) to four (4) 'Class A' for Model FC924
  - Includes one (1) 'Class A' or two (2) 'Class B' notification appliance circuits (NACs)
  - Resettable and non-resettable 24VDC, [nominal] auxiliary power
  - Connectivity to a leased-line / city-tie module
  - Releasing module supports activation of releasing valves in pre-action / deluge systems / agent release
  - Off-normal warning message prior to reset
  - Fast and easy set-up with auto-configuration feature
  - Cerberus® DMS Danger Management Station can monitor and control up to 32 Models FC922 and FC924 FACP's
  - Digital alarm communication transmitter (DACT)
- **UL 864 9<sup>th</sup> Edition Listed, ULC Listed;**  
**FM, CSFM & NYC Fire Department Approved**

### Product Overview

The Cerberus PRO 252-point (Model FC922) / 504-point (Model FC924) addressable FACP is designed to meet the fire-protection needs of mid-size buildings.

This advanced FACP offers features typically required in mid-size buildings in a package that is easy to install and competitively priced. Additionally, Models FC922 and FC924 are networkable, allowing the systems to fulfill the growing fire-protection needs of the building. The programming software for the 252 / 504-point fire systems is held in flash electrically erasable programmable read-only memory (EEPROM).

The following Cerberus PRO system components are used in the 252-point / 504-point FACP:

- Operating units
- Periphery boards
- Power supplies
- System enclosures

Other options are available to meet specific needs. Models FC922 and FC924 are FM (#3010); CSFM (#7165-0067:0259) and FDNY (#6104) Approved.



**Cerberus PRO Two-Height-Unit (2HU)  
Enclosure with two (2) cutouts**

### Specifications

#### Operating Interface Unit

The Operating Interface Unit (Model FCM2018-U3 or Model FCM019-U3) functions as the operating interface and central microprocessor for Models FC922 and FC924.

Either operating interface unit provides multi-use capability for each end-user to efficiently 'Acknowledge' events; to quickly control the NACs of the FACP, and to permit a manual reset of the respective system. Detailed data about the nature and location of the events can also be displayed, via a backlit, 2" –x– 4-3/4" (5.1 cm. –x– 12.1 cm.) LCD screen and the four-way navigation push button at the top of the FACP.

#### Periphery Boards

The periphery boards (Models FCI2016-U1 and FCI2017-U1) serve as the main operating components for the 252 / 504-point FACP. Each module operates and monitors input-device identity; as well as controls the signaling-line circuits that communicate with smoke detectors and other field devices (i.e. – C-NET).

# Cerberus® PRO

Fire Safety Products

# 9815

FACP for mid-size buildings

## Specifications – (continued)

### Power Supplies

All functions are supported by the power supplies (Model FP2011-U1 or Model FP2012-U1), which therefore eliminate the need for external power supplies.

Further, the 170-Watt power supply (Model FP2011-U1) and 300-Watt power supply (Model FP2012-U1) provide primary, 24VDC nominal power for normal operation to Models FC922 and FC924. Both power supplies are filtered and regulated. Model FP2011-U1 is rated at 6.5 Amps, and the rating for Model FP2012-U1 is 11.5A.

The 170-Watt power supply incorporates a 4.0A, non-resettable slow-blow fuse on the primary input, and includes a built-in AC-line filter for surge and noise suppression. Model FP2011-U1 mounts in the FACP enclosure, and there are no serviceable Cerberus PRO parts to be maintained.

The 300-Watt power supply incorporates two (2) 6.3A replaceable, non-resettable slow-blow fuses on the primary input and includes a built-in AC line filter for surge and noise suppression. Model FP2012-U1 mounts in the FACP's enclosure, and there are no serviceable Cerberus PRO parts to be maintained.

### System Enclosures

The Cerberus PRO fire-alarm enclosures and their accessories provide a complete set of hardware for mounting all Cerberus PRO main-system and remote terminal cards and modules.

The hardware allows this Cerberus PRO system to be configured for a variety of applications, as well as for future system upgrades. Included in the enclosure series are back box and door sets; removable mounting plates and clear lenses, as well as blank plates for use with the enclosure doors.

All enclosures come with ground straps for the inner and outer doors, shield termination lugs, grounding lugs, and tie wrap lances for securing wire. All Cerberus PRO height-unit enclosures can also mount system back-up batteries up to 33AH in capacity.

Models FC922 and FC924 utilize a two-height-unit enclosure. The following components comprise a complete two-height-unit enclosure:

- One (1) back box, (Model FHB2002-U1 / R1)
- One (1) or two (2) inner doors, (Models FHD2004-U1 or FHD2005-U1)
- One (1) outer door, (Model FHD2002-U3 / R3 or FHD2003-U3 / R3)
- One (1) or two (2) clear windows, (Model FHD2006-U1)

**Note:** One (1) window is installed for Model FHD2002-U3 / R3 outer door, and two (2) windows are required for Model FHD2003-U3 / R3.

The approximate size for each two-height-unit enclosure is: 27.5" (70cm.) high; 21.5" (54.6cm.) wide, and 5.75" (14.6cm.) deep. The weight, without any attached components, is approximately 6.3 Lbs. (2858 g).

Additionally, the two-height-unit enclosure supports the following optional components:

- Enclosure trim kit (for flush-mounting)
- Battery bracket (to comply with seismic certification)
- DIN rail kit (provides connection between internal-system wiring and field wiring)

### Optional Accessories

#### Digital Alarm Communication Transmitter (DACT)

The DACT is used to provide communication between Models FC922 and FC924 and with either a central or remote monitoring station.

The Model FCA2015-U1 module mounts directly on the back enclosure and connects to the periphery boards. The DACT enables remote transmission of alarms and events via a public telephone line.

#### Releasing Module

The releasing module (Model XCI2001-U1) supports activation of releasing valves in pre-action / deluge systems (including double-interlock pre-action systems, or Sinorix® Engineered Fire Suppression systems). Activation can be event-controlled or performed by addressable manual pull stations. The releasing module is installed on the periphery board, and supports 'Class B' releasing circuits.

When installed on Models FC922 / FC924, the releasing module contains an integral manual-disconnect switch for releasing circuits. This essential feature protects the releasing circuits from accidental discharge during maintenance.

#### Leased-Line / City-Tie Module

Model FCI2020-U1, which is installed on the periphery board of the FACP, provides a local-energy output for municipal call-box connection, and gives a reverse-polarity output for leased-line connection.

When used for connection to a municipal call box, the city-tie function supports *Alarm*-event transmission. When used for leased-line connection, the module supports two (2) leased telephone lines for transmitting *Alarm*, *Trouble* and *Supervisory* events.

#### Battery Disconnect Module

The Battery Disconnect Module (Model FCA2032-U1) is specifically designed to disconnect the backup battery on the Cerberus PRO 252 / 504-point addressable FACP when its voltage drops below 19VDC. Model FCA2032-U1's cut-off capability prevents the battery from operating beyond its normal power level for basic system operation.

The battery-disconnect module remains disconnected until AC power is restored to the Cerberus PRO 252 / 504 FACP.

## Specifications — (continued)

### Network Module

The C-WEB network module (Model FN2001-U1) is used to network up to 16 FACPs, or one (1) fire terminal, via the C-NET system bus. Model FN2001-U1 is plugged into the Operating Unit (or an Operating Unit with built-in LEDs).

Model FN2001-U1, which connects to a system input / output bus, has ground-fault monitoring, as well as an integrated degrade-mode feature. Redundant networking is done with one (1) network module per FACP [Simple-Loop Trouble]. There is electrical isolation between the system bus and FACP.

### Remote Display Terminals

The Remote Display Terminals (Models FT2014-U3 / R3 and FT2015-U3 / R3) are remote annunciators that show the existing status of Models FC922 / FC924.

Light-emitting diodes (LEDs) will illuminate for any given *Alarm*, *Supervisory* and *Trouble* Cerberus PRO-system event. A LCD screen will give details of the event in alphanumeric form. The display screen can be scrolled, via the four-way navigation button, to reveal additional events.

Model FT2014-U3 / R3 is a display-only remote annunciator that has one (1) button used to silence the local sounder. Model FT2015-U3 / R3 has three (3) control buttons for ‘acknowledging’ events, ‘silencing’ audible circuits and ‘resetting’ the system. Additionally, there are three (3) user-programmable buttons available. Model FT2015-U3 / R3 has an integral key switch that enables the control buttons to operate.

The remote display terminals are remotely connected to Models FC922 and FC924, via the RS-485 interface. Models FC922 and FC924 require the Model FCA2016-U1 RS-485 module to provide communication to the remote display terminals. Model FCA2016-U1 supports Style 4 or Style 6 wiring. Up to eight (8) modules can be supported on a RS-485 bus.

The remote display terminals require 24VDC [nominal] power, and the necessary power can be provided from this Cerberus PRO FACP or from another @UL Listed, 24VDC power source.

**Note:** A Model FHD2012-U1 inner door can be optionally purchased in @UL markets. The inner door mounts with the optional Model FT201x-series Remote Display terminals. Having a Model FHD2012-U1 inner door installed can assist in preventing unauthorized access to the RDT.

### L1 License Key

The L1 License Key is used as a means for accessing a real-time view of current system status between a 252 / 504-point addressable FACP and the laptop of the end-user.

Each key (Model FCA2012-U1) allows an end-user to perform basic or vital system functions virtually in the same precise manner as if the end-user was physically present at the FACP that is triggering a system event.

System-status conditions are clearly displayed on the end-user’s PC monitor.

### Tabular Annunciators

Tabular annunciators allow system events sent from Cerberus PRO addressable panels to be displayed remotely in real-time. The Model FT2008 series of tabular annunciators has 16 zones, and the Model FT2009 series uses 96 LEDs for 32 zones. Up to two (2) light-emitting diodes (LEDs) can be used per zone.

Tabular annunciators provide outputs for system and zone status, and are orderable in either **black** or **red**.

### LED Annunciator Driver

The Model FT2007-U1 LED Annunciator Driver provides custom graphic annunciators on addressable Cerberus PRO FACPs. This optional system module provides 96 highly programmable outputs to drive LED indicators.

There are 16 inputs to accommodate user-system commands: *Silence*, *Unsilence*, *Reset*, *Acknowledge* and *Lamp Test*. Model FT2007-U1 is supervised via a RS-485 interface. A maximum eight (8) modules are allowed on each RS-485 communication bus.

### NAC Expansion Module

The NAC expansion module (Model FCI2011-U1) provides either of the following additional NACs to a Cerberus PRO 252 / 504-point FACP:

- one (1) ‘Class A’, or
- two (2) ‘Class B’ NACs

Each NAC is rated at 3 Amps. Each NAC expansion module is monitored for open-line and short-circuit conditions.

## Details for Ordering

Model	Part Number	Description
FCI2016-U1	S54400-A55-A1	Periphery Board, 252-pt. FACPs
FCI2017-U1	S54400-A56-A1	Periphery Board, 504-pt. FACPs
FCM2018-U3	S54400-C40-A2	Operating Interface Unit
FCM2019-U3	S54400-C41-A2	Operating Interface Unit with LEDs
FHB2001-U1	S54400-B47-A1	1HU Back Box, <b>Black</b>
FHB2001-R1	S54400-B47-A2	1HU Back Box, <b>Red</b>
FHB2002-U1	S54400-B48-A1	2HU Back Box, <b>Black</b>
FHB2002-R1	S54400-B48-A2	2HU Back Box, <b>Red</b>
FHD2001-U3	S54400-B45-A1	1HU Outer Door, <b>Black</b>
FHD2001-R3	S54400-B40-A1	1HU Outer Door, <b>Red</b>
FHD2002-U3	S54400-B32-A1	2HU Outer Door w/ 2 Windows, <b>Black</b>
FHD2002-R3	S54400-C53-A1	2HU Outer Door w/ 1 Window, <b>Red</b>
FHD2003-U3	S54400-C42-A1	2HU Outer Door w/ 2 Windows, <b>Black</b>
FHD2003-R3	S54400-B46-A1	2HU outer door w/ 2 windows, <b>Red</b>
FHD2004-U1	S54400-B52-A1	Inner Door, <b>Black</b>
FHD2005-U1	S54400-B53-A1	Inner Door, <b>Black</b> (full plate)
FHD2006-U1	S54400-C46-A1	Clear-Lens Window
FP2011-U1	500-450222	170-Watt Power Supply
FP2012-U1	S54400-Z60-A1	300-Watt Power Supply

## Details for Ordering – (continued)

### Optional Accessories

Model	Part Number	Description
FCA2012-U1	S54400-P102-A1	L1 License Key
FCA2015-U1	S54400-A63-A1	Digi. Alarm Comm. Transmitter [DACT]
FCA2016-U1	S54400-A39-A1	RS-485 Interface Module
FCA2018-U1	S54400-A65-A1	Remote Peripheral Module
FCA2032-U1	S54400-B145-A1	Battery Disconnect Module
FCI2011-U1	S54400-A54-A1	NAC Expansion Module
FCI2020-U1	S54400-A57-A1	Leased-Line / City-Tie Module
FCM2022-U3	S54400-C44-A2	Blank Option Module
FCM2023-U3	S54400-C45-A2	LED Option Module: [Red / GREEN bi-color LED; one (1) YELLOW LED]
FCM2034-U3	S54400-C138-A1	LED Option Module: [Red / YELLOW bi-color LED; one (1) YELLOW LED]
FHD2012-U1	S54400-C145-A1	Inner Door, <b>Black</b> (optional, ©UL markets)
FN2001-U1	S54400-A60-A1	C-WEB Network Module
FN2006-U1	S54400-A61-A1	Single-Mode Fiber-Optic Module
FN2007-U1	S54400-A62-A1	Multi-Mode Fiber-Optic Module
FT2007-U1	S54400-A142-A1	LED Annunciator Driver
FT2008-U1	S54400-A143-A1	16-Zone Tabular Annunciator, <b>Black</b>
FT2008-R1	S54400-A144-A1	16-Zone Tabular Annunciator, <b>Red</b>
FT2009-U1	S54400-A145-A1	32-Zone Tabular Annunciator, <b>Black</b>
FT2009-R1	S54400-A146-A1	32-Zone Tabular Annunciator, <b>Red</b>
FT2014-U3	S54400-B80-A1	Remote Display Terminal, <b>Black</b>
FT2014-R3	S54400-B73-A1	Remote Display Terminal, <b>Red</b>
FT2015-U3	S54400-B88-A1	Display Terminal with key, <b>Black</b>
FT2015-R3	S54400-B16-A1	Display Terminal with key, <b>Red</b>
FTI2001-U1	S54400-A58-A1	Fire Terminal Board
XCI2001-U1	S54400-A69-A1	Releasing Module

### Related Documentation

Product	Data Sheet Number
Cerberus PRO operating units	9801
Cerberus PRO periphery boards	9802
Cerberus PRO fire terminals	9803
Cerberus PRO DACT	9804
C-WEB / C-NET Network Module	9805
Cerberus PRO power supplies	9806
Cerberus PRO enclosures	9807
NAC expansion module	9808
Cerberus PRO releasing module	9809
Leased-Line / city-tie module	9810
Remote periphery module	9811
Remote display terminals	9812
Single / multi-mode fiber modules	9814
LED / Blank option modules	9816
Battery disconnect module	9819
L1 license key	9820
Marine-specific equipment	9822
LED annunciator driver	9824
16 & 32-zone tabular annunciators	9825

## SIEMENS Cerberus® PRO

Siemens Industry, Inc. – Building Technologies Div.  
8 Fernwood Road • Florham Park, NJ 07932  
Tel: (973) 593-2600 • Fax: (908) 547-6877  
Web: [www.USA.Siemens.com/Cerberus-PRO](http://www.USA.Siemens.com/Cerberus-PRO)

**NOTICE** – The information contained in this data-sheet document is intended only as a summary, and is subject to change without notice. The devices described here have specific instruction sheets that cover various technical, limitation and liability information.

Copies of these instruction sheets and the *General Product Warning and Limitations* document, which also contains important information, are provided with product and are available from the Manufacturer.

Information contained in these documents should be consulted before specifying or using the product. For further data or assistance, please contact the Manufacturer.

### Electronics Packages

Model	Part Number	Description
FC922-US	S54400-C14-A1	252-Point Fire System with 170 Watt Power Supply and standard operator interfaces
		Includes: FP2011-U1 (1 Qty.) FCI2016-U1 (1 Qty.) FCM2018-U3 (1 Qty.)
FC924-US	S54400-C15-A1	504-Point Fire System with 170 Watt Power Supply and standard operator interfaces
		Includes: FP2011-U1 (1 Qty.) FCI2017-U1 (1 Qty.) FCM2018-U3 (1 Qty.)
FC922-UE	S54400-C16-A1	252-Point Fire System with 170 Watt Power Supply and standard operator interfaces (with 24-zone LEDs)
		Includes: FP2011-U1 (1 Qty.) FCI2016-U1 (1 Qty.) FCM2019-U3 (1 Qty.)
FC924-UE	S54400-C17-A1	504-Point Fire System with 170 Watt Power Supply and standard operator interfaces (with 24-zone LEDs)
		Includes: FP2011-U1 (1 Qty.) FCI2017-U1 (1 Qty.) FCM2019-U3 (1 Qty.)
FT924-US	S54400-C18-A1	Network Terminal w/ standard operator interface
		Includes: FTI2001-U1 (1 Qty.) FCM2018-U3 (1 Qty.)
FT924-UE	S54400-C19-A1	Network Terminal w/ standard operator interface (with 24-zone LEDs)
		Includes: FTI2001-U1 (1 Qty.) FCM2019-U3 (1 Qty.)
FC922-UT	S54400-C20-A1	252-Point Fire System with 300 Watt Power Supply and standard operator interfaces
		Includes: FP2012-U1 (1 Qty.) FCI2016-U1 (1 Qty.) FCM2018-U3 (1 Qty.)
FC924-UT	S54400-C21-A1	504-Point Fire System with 300 Watt Power Supply and standard operator interfaces
		Includes: FP2012-U1 (1 Qty.) FCI2017-U1 (1 Qty.) FCM2018-U3 (1 Qty.)
FC922-UF	S54400-C22-A1	252-Point Fire System with 300 Watt Power Supply and standard operator interfaces (with 24-zone LEDs)
		Includes: FP2012-U1 (1 Qty.) FCI2016-U1 (1 Qty.) FCM2019-U3 (1 Qty.)
FC924-UF	S54400-C23-A1	504-Point Fire System with 300 Watt Power Supply and standard operator interfaces (with 24-zone LEDs)
		Includes: FP2012-U1 (1 Qty.) FCI2017-U1 (1 Qty.) FCM2019-U3 (1 Qty.)

### Temperature and Humidity Range

Models FC922 and FC924 are @UL 864 9<sup>th</sup> Edition Listed for indoor dry locations within a temperature range of 120 +/- 3°F (49 +/- 2°C) to 32 +/- 3°F (0 +/- 2°C) and a relative humidity of 93 +/- 2% at a temperature of 90 +/- 3°F (32 +/- 2°C).